

LEAVE ALL BOLTS AND NUTS FINGER TIGHTENED UNTIL ALL ARE IN PLACE

- 1. Lay the Table Top on an Even Flat Surface with the Best Side Facing the Ground. The Fiberglass Top will have Pre-Driled Holes To Accept The 3/8"x 7/8" Flanged Hex Head Bolt.
- 2. Assemble The Leg Sets As Shown On Sheet No. 3, Align the Holes In the Angle Iron Top Bracket With The Holes In The Fiberglass Top. Face The Angle Iron Top Brackets As Shown At Right.
- the Legs will use a 3/8"-16x 4 3/4" Hex Head Bolt with Lock Washer
- 5. There Will be Left and Right Seat Cleats, Fasten as Shown to the Under Side of the Seat Planks, Then Attach Them to the Legs.

NO.

3

4

5

10

12

2BG-1

2BG-3L

2BG-3R

IBG-2

BG-5

6IF-8

6IPTF-9

IN-HWMS 0.375-

14 Regular FW 0.375

6x0.875x0.875-N

N-HWMS 0.375-16x1x1-

the Bolts and Nuts

3/8"-16x 7/8" FLANGED HEX HEAD BOLT


3/8"-16x 1" FLANGED HEX HEAD

3/8" REGULAR FLAT WASHER

16

1

8



PATH TO PART OR ASSM - S:\CADDRWG\$\Solidworks\Tables\BG\

CONFIDENTIAL DRAWING.

DISCLOSED TO OTHERS WITHOUT

CONSENT OF KAY INDUSTRIES. SPECIFICATIONS SUBJECT TO CHANGE

WITHOUT NOTICE

INFORMATION IS NOT TO BE COPIED OR

LAST SAVED

9

8/27/2018 DESC:

Configuration - Default

davet 8/28/2018 PART NO: 62BGF

MATL:

6 FT. BG TABLE FIBER GLASS SEATS and TOP

8/28/2018 07:24:11

SHEET 2 OF 3

