## ASSEMBLY INSTRUCTIONS ROCK ISLAND BENCH

**STEP 1:** PLACE THE BENCH LEGS FACING UPRIGHT ON A LEVEL SURFACE. (ESTIMATE SPACING).

STEP 2: PLACE 3 OF THE 2 X 6 BOARDS ONTO THE SEAT ALIGNING THE HOLES IN THE BENCH LEGS WITH THE PILOT HOLES IN THE 2X6'S. FASTEN THE BOARDS TO EACH BENCH LEG FROM THE UNDERSIDE OF THE BENCH LEGS USING 6 OF THE 2-1/4" SCREWS PER BENCH LEG. USE OF A POWER DRIVER WITH A PHILLIPS #3 (LARGE) BIT IS RECOMMENDED – DO NOT OVER TIGHTEN.

STEP 3: PLACE ONE OF THE 2 X 6 BOARDS ONTO THE BACK OF THE BENCH. ALIGN THE HOLES IN THE BACK OF THE BENCH LEGS WITH THE PILOT HOLES IN THE BOARDS. ATTACH THE BOARD TO THE BENCH LEGS USING 2 OF THE 2-1/4" SCREWS PER BENCH LEG. REPEAT FOR THE REMAINING 2 X 6.

	4'	6'	8'	
REF#	QTY	QTY	QTY	DESCRIPTION
1	5	5	5	2" X 6" PROFILE
2	2	3	4	ROCK ISLAND BENCH LEG
3	20	30	40	HARDWARE KIT #14 X 2-1/4" SS FH PHILLIPS SCREW

**NOTE**: PROFILES MAY BE DIRECTIONAL AND YOU MAY NEED TO TURN THEM END-FOR-END IF THEY DO NOT LINE UP SQUARELY.