

PLANK INSTALLATION:

PATH TO PART OR ASSM - 6BGA

There are two different kinds of planks. Be sure to have these separated out and identified before you begin assembly. a. Anodized 2" x 10" seat plank (it has a dull finish that does not leave a mark when rubbed).


b. Mill finish 2" x 10" foot plank and walkway plank (it has a shinier finish that leaves a black mark when rubbed with your finger or thumb)

Put a hold down clip on each hole of the seat brackets and foot board supports using 5/16"x 1-1/4" carriage bolt, flange nuts. Keep the long way of the clip parallel with the length of the bleacher (or perpendicular to the frames). Place the mill finish foot planks over the clips starting on the foot angles.

Do not tighten all of the clips yet. Only tighten the clips on the ends at this point. The planks should overhang the seating frames by about 17" on each side.

> CONSENT OF KAY INDUSTRIES. SPECIFICATIONS SUBJECT TO CHANGE

WITHOUT NOTICE. S:\CADDRWGS\Solidworks\Tables\BG\



AST SAVED

johnb

Configuration - DEFAULT

5/31/2017 PART NO: 6BGA

5/31/2017 11:48:29 AM

SHEET 3 OF 3